

# Addendum for all tassel-corded window covering Installation Guides

The following instructions either replace a step near the end of each guide :  
“Mounting the Cord Cleat”  
or, if non-existent, must be added as a final step

## Improved Safety Tie-Down Cleat

A new safety tie-down cleat has been supplied with your blind to comply with new and improved child safety laws. **This device must be attached to the surrounding wall or frame for your blinds to be safety compliant.**



You will have received either one (*fig a*) or two sets of cleats, depending on the type of blind you purchased, and its height. Or you may have received two or four cleats, if your blind has cords on opposite sides.



**1.** Position the device on the wall or moulding, then insert the supplied screw into each hole and install. Cleat should be placed 64” (1.63m) from the floor. Install a second cleat 6” to 12” (15-31cm) above the first, if two cleats are required to hold the cords.

**2.** After adjusting the blind to the desired height, attach the cord snugly to the cleat(s) using a “figure-8” pattern. See example (*fig b*) for a single cleat or (*fig c*) for two cleats. **Always resecure cords after adjusting your blind.**

**3.** Repeat as necessary until all hanging tassel cords are secured.

**Note:** Use appropriate wall anchors where necessary.

The cleat device described above replaces the following devices:

